



1. Power (On/Off):
2. Cycle/Stop: press to step the tape forward
3. Auto/Stop: light on, tape will run automatically through the feeder continuously.
4. Speed Control: control the timing of each step when using the Auto function.